

Windsor Stainless Steel Wire with Stainless Steel Posts Assembly Instructions

These assembly instructions only relate to horizontal stainless steel balustrading. We are unable to supply stainless steel balustrading for steps.

1. Erect Stainless Steel Upright Posts.
2. Put Steel Cover Plate over base plate.
3. Attach Saddles/Universal Fittings to pre-drilled rails with screws (supplied).
4. Assemble and glue rail plus saddles and/or elbows into top of Upright Posts.
5. Then attach stainless steel wire by
 - a) Attaching End Fixing Unit/Tensioner Unit to one external pre-drilled Upright Post.
 - b) Thread wire through Intermediary Posts.
 - c) Attach second End Fixing Unit/Tensioner to other external pre-drilled Upright Post.
 - d) Tighten End Fixing Units/Tensioners.